



// ONE BRAND // ONE SOURCE // ONE SYSTEM

C320 WHITE CEMENT Bonding Procedures

REMA TIP TOP's non-flammable and versatile C320 Cement, when catalyzed with the appropriate amount of REMA TIP TOP UT-R 20 Hardener provides all the advantages and strength of our SC2000 Cement. Developed for use in splicing light and heavy duty industrial belting, Cement C320 is suitable for the repairs and endless splicing of chloroprene belts, bonding rubber to metal, fabric to fabric, and rubber to fabric. C320 Cement is also used for splicing fabric carcass belts and will bond a wide range of elastomers commonly used in the food processing industry. For example, C320 is used for bonding cleats to belting and pulley lagging to metal.

Description

C320 White Cement is a two component, room temperature curing chloroprene based liquid rubber adhesive that, when catalyzed with the appropriate amount of **UTR20 or ER42 Hardener**, yields high strength adhesions. **C320 White Cement** is ideal for use in lining installations, when bonding rubber to rubber, rubber to fabric, rubber to steel, rubber to concrete, fiberglass, and urethane, as well as the splicing and repair of fabric conveyor belting. Repair to existing rubber lined vessels and rubber components are also recommended.

Mixing instructions

The **C320 White Cement** system is comprised of cement and hardener in the ratio of 1 Kg of cement to 40 grams of **UTR20 Hardener OR 30 grams of ER42 Hardener**. The cement and hardener must be thoroughly mixed (stirred) for at least 2 minutes. The mixed portion should be used within 2 hours.

General Rubber Lining Environmental Conditions

Before any sandblasting, application of metal primer, adhesives or application of lining material the ambient temperature and that of the substrate must be at least + 50° Fahrenheit with a maximum temperature of + 104° to +113° Fahrenheit.

The Relative Humidity should not exceed 80% during the entire lining procedure.

The substrate temperature must be a minimum of 5 degrees higher than that of the dew point. Relative humidity, ambient temperature, substrate temperature and dew point must be recorded prior to start of project and at three hour intervals thereafter.

Surface Preparation & Application Methods

RUBBER TO STEEL

All surfaces must be clean, dry and free of oil, paint and other contamination. Steel and other metallic surfaces should be sandblasted to a 2-mil blast profile (SSPC-SP10 "Near White Metal Blast Cleaning") to obtain maximum adhesion. A brushing application to all substrates is the preferred method to avoid possible bridging of a high profile surface. Metal surfaces should first be cleaned with **REMA TIP TOP Solvent** and then sandblasted and cleaned again with **REMA TIP TOP Solvent**. After the surface is prepared it should be primed with **REMA TIP TOP PR200 Metal Primer**. The primer should be allowed to dry completely, approximately 1 hour depending upon atmospheric conditions. After allowing the prime coat to cure or dry for at least 1 hour, proceed with bonding procedures.

FIBERGLASS

The surface should be prepared by first cleaning with **REMA TIP TOP Solvent**, then sanded, and re-cleaned with **REMA TIP TOP Solvent** to help remove abraded particles. Allow the solvent to evaporate. Then the prepared surface must then be primed with **C320 White Cement**. The prime coat of cement should be allowed to completely cure at least 1 hour (overnight is ideal). After allowing the prime coat to cure or dry for at least 1 hour, proceed with bonding procedures.

RUBBER TO RUBBER

The surface should be prepared by first cleaning with **REMA TIP TOP Solvent** to remove all mould releases. Rubber that does not have the special **REMA TIP TOP CN bonding layer**, requires cleaning with **REMA TIP TOP Solvent** and when



Surface Preparation & Application Methods (continued)

dry, buffing to a RMA #4 textured finish. The rubber dust should be removed with a dry brush and then wipe the surface with **REMA TIP TOP Solvent** again before the prime coat (dry-coat) of **C320 White Cement** is applied to the prepared surface. The applicator should use a scrubbing-like motion when applying the **C320 White Cement**. A scrubbing motion is preferred so that all voids on the buffed surface to be bonded are filled in. After allowing the prime coat to cure or dry for at least 1 hour (overnight is ideal) proceed with bonding procedures.

CONCRETE

The best surface preparation for concrete is sandblasting to provide a clean, dry and sound substrate. When sandblasting is not practical, the surface may be acid etched following the manufacturer's recommendations. After sandblasting or etching, the surface must be primed with **C320 White Cement**. For ease of application the prime coat could be roller applied by diluting the **C320 White Cement** with **REMA TIP TOP #13 solvent**, about 25%. This dilution will assure better absorption. The second coat (dry-coat) of **C320 White Cement** must not be diluted for optimum adhesion.

WOOD

The best surface preparation for wood is sandblasting. Wood must be dry. After sandblasting, the surface must be primed with **C320 White Cement**. For ease of application the prime coat could be roller applied by diluting the **C320 White Cement** with **REMA TIP TOP #13 solvent**, about 25%. This dilution will assure better absorption. The second coat of **C320 White Cement** must not be diluted for optimum adhesion.

FABRIC TO FABRIC

Fabric that is R.F.L. treated should be clean and dry and the number of coats of **C320 White Cement** will depend on the weight and weave of the fabric. Take special care to insure all indentations are filled (such as heavy conveyor belt fabric).

BONDING

When applying the **C320 White Cement** a scrubbing motion is preferred so that all voids on the surface to be bonded are filled in. The first coat of cement should be allowed to completely cure at least 1 hour (overnight is ideal) before the second coat, or "tack coat" is applied. To the properly prepared or primed surfaces apply a tack coat of **C320 White Cement** to each surface at the same time so they dry at the same rate. As rapidly as possible, apply a uniform coat with a brush. Avoid heavy builds, puddles, uneven coating. Surfaces must dry uniformly. When surfaces dry to a tack, about 3-6 minutes, they are ready to bond (if the surfaces become too dry, apply another tack coat to each). Test the cement with the back of a dry finger, it should feel tacky and not leave any cement on the finger.

SURFACES MUST BE TACKY WHEN BONDED. Join surfaces together when the cement is still tacky but not wet to the touch. Roll with a 2" wide roller (stitcher) with appropriate pressure to bond surfaces together. Use overlapping roller strokes making sure both surfaces fully contact each other and all air is expelled.

For additional information contact your **REMA TIP TOP** rubber specialist.

Bond Evaluation

C320 White is capable of bonding rubber to steel in the range of 60-70 lbs. peel per inch width. Bond strengths of fabric to fabric, such as fabric conveyor belting, can develop over 500 lbs. in shear.

Bond strengths measured in lbs. per inch peel strength

	2 hrs	5 hrs	12 hrs	24 hrs	7 days
Rubber to Steel	60	63	64	65	72
Rubber to Rubber	24	29	34	40	60
Fabric to Fabric	20	24	25	28	32
Rubber to Fabric	18	24	26	28	55



// ONE BRAND // ONE SOURCE // ONE SYSTEM

Pot Life

The gel time or working life of mixture is approximately 2 hours at 70° F.

Coverage

Approximately 22 to 27 sq. ft. per 1 kg./ per coat by brush coating.

Physical Properties

Color:	White
Weight per Gallon:	12.1 lbs.
Consistency:	Brushable liquid
Diluents:	Trichloroethylene
Oil Resistance:	Excellent
Application Temp:	+50° to 113° F (+10° to +45° C)
Maximum Constant Operating Temp:	212° F (100° C) Rubber to Metal 176° F (80° C) Rubber to Rubber 176 F (80 C) Rubber to Fabric

Storage

Shelf life of unopened containers is 4 years. **C320 White Cement** and hardener should be stored in a cool dark place away from heat, sparks and flame under 70° F (20° C).

Safety

C320 White Cement contains solvents; the inhalation of excessive amounts of vapor may induce an allergic respiratory reaction to sensitized individuals. Proper respiratory protection must be used. Avoid skin contact. Wear protective clothing, impervious rubber gloves, and safety glasses. In case of skin contact, wash well with soap and water. Spills should be absorbed with absorbent material and water added to destroy isocyanates. When applying **C320 White Cement** in confined areas, suction ventilation equipment should be in operation. The equipment should be arranged so that vapors are drawn down and away from the applicator. **C320 White Cement** is non-flammable. The **UTR20** or **ER42 Hardener** is flammable although when mixed together they become non-flammable. As always the usual fire safety measures should be observed. Keep away from heat, sparks and open flame. Do not use until the SAFETY DATA SHEET and INSTRUCTIONS have been read and understood.

Packaging Sizes and Hardener Amounts

C320 White Cement	UTR20 Hardener	OR	ER42 Hardener
1/2 kg	1 x 20 g		1 x 15 g
1 kg	1 x 40 g		1 x 30 g
5 kg	5 x 40 g		5 x 30 g

The recommendations for the use of our products are based on tests believed to be reliable but no warranty is given. Since conditions of use are beyond our control the user assumes all risks of use.

For Technical Assistance and Professional Advice

Please Contact your Local REMA TIP TOP Agent or Call (800) 334-REMA